

GRAND VISION

USER MANUAL

REV1.1

用户手册

GRAND VISION

REV1.1

附件清单

Components

INTEL LGA 115X/1700 Adjust Intel backplate

INTEL LGA 115X/1700 安装背板

INTEL LGA 115X/1200 安装

INTEL LGA 115X/1200 Installation

INTEL LGA 1700/1851 安装

INTEL LGA 1700/1851 安装

INTEL LGA 20XX 安装

INTEL LGA 20XX Installation

AMD AM4/AM5 安装

AMD AM4/AM5 安装

风扇与冷排安装

Fan/Radiator Mounting

Waterlock/Fan Guide

冷头/风扇使用说明

水泵接线说明

PUMP CONNECT GUIDE

LCD screen wiring

屏幕接线

冷头上盖操作说明

Rotate waterlock panel.

GRAND VISION 系列水冷屏屏投软件说明

1. 将屏投软件插入主板USB接口，按照屏投软件提示进行安装。

2. 可在屏投软件安装过程中选择安装语言。

3. 安装完成后，可在屏投软件安装目录下找到屏投软件。

4. 安装完成后，可在屏投软件安装目录下找到屏投软件。

5. 如遇屏投软件无法安装，可联系售后服务。

GRAND VISION DISPLAY USER GUIDE

1. Check if the SATA cable connect to the sata socket on motherboard and connect SATA cable to the power supply before software install.
2. Download software at: <https://www.thermaltake.com/support/download/>
3. After install completed, double click shortcut icon on desktop to run software.
4. All functions on LCD are controlled by software, and software will auto start at OS boot. Please do not exit the program.
5. For unknown error, please restart the computer.

产品保修卡

产品名称: _____

序列号: _____

生产日期: _____

保修期限: _____

保修说明: _____